

BNCLUTCH AND BRAKE PEDAL LEVERSCard 1

400	CLUTCH PEDAL LEVER	1	1A	3616
401	Stalk and pad	1	1A	3631
402				
403	Clutch Pedal spring	1	1A	3607
404	Adjustment washers	6	1F	3008
405	Adjustment washers	6	1F	3009
406	Adjustment washers	6	1G	3048
407	Bolt, clutch pedal lever to oper. shaft	1	2K	3140
408	Spring washer	1	2K	1212
409	Setscrew for clutch pedal lever	1	2K	3094
410				
411	Spring washer	1	2K	1211
412	BRAKE PEDAL LEVER with stalk & pad	1	1A	5641
413	Setscrew	1	2K	3094
414	Spring washer	1	2K	1211
415	Rubber for pedal pads	2	1A	3208
416	Rubber washer for stalks	2	2K	5003
417	Metal washer for stalks	2	2K	4896
418	<i>Grease nipple for brake pedal lever</i>	1	<i>2H. 1129</i>	

continued.

BN

BRAKE PEDAL ROD AND SHAFT

Card 2

420	BRAKE PEDAL ROD	1	1A 5690	
421	Nut for rod	1	1A 5513	
422				
423	BRAKE PEDAL JAW	1	1A 5018	
424				
425	PEDAL RETURN SPRING	1	1A 5691	<i>FROM 13669</i>
426	Joint pin	1	1A 5696	<i>OR 2K.5828</i>
427				
428	Split pin	1	2K 1231	<i>FOR ABOVE 2K/238</i>
429				
430	Brake rod and tension spring	1	1A 5692	
431				
432	BRAKE PEDAL SHAFT	1	1A 5642	
433	Nut for pedal shaft	1	2K 5132	
434	Washer	1	2K 1206	
435	Split pin	1	2K1234	
436				
437	Foot brake lever trunnion	1	1A 5700	

continued.

BNBRAKE CROSS SHAFT AND LEVERSCard 3

440	BRAKE CROSS SHAFT	1	1A	5683
441				
442	Front brake operating lever	1	1A	5686
443				
444	Rear brake operating lever	1	1A	5687
445	Keys for levers	2	2K	5565
446	Clamping bolts for levers	2	2K	6201
447	Nuts	2	2K	3977
448	Spring washers	2	2K	1212
449	Lockwashers	2	2H	684
450	CROSS SHAFT CENTRE BEARING complete	1	1A	5697
451	Bolts	2	2K	5282
452	Nuts	2	2K	3975
453	End cap for shaft	1	1G	5418
454	Felt ring for cap	1	2K	6614
455	Felt rings for cross shaft	4	2K	4840
456	Washers for felts	2	2K	5255
457	Spring ring	1	1A	5483

CEASED

FROM 17.764

OCT. 1938 - 477

continued.

BNBRAKE RODS, LINKS AND BRACKETSCard 4

460	Cross shaft safety bracket	1	1A	5693			
461	Bolts, for bracket	3	2K	8882			
462	Nuts	3	2K	3976			
463	Spring washers	3	2K	1211			
464	BRAKE ROD, cross shaft to link	1	1A	5695			
465	BRAKE ROD, link to rear axle	1	1A	5694			
466	Forks for rods	2	1G	5437			
467	Locknuts	2	2K	3975			
468	Joint pins	2	2K	4906			
469	Split pins	2	2K	1227			
470	Felt rings	4	2K	5220			
471	REAR BRAKE LINK	1	1A	5660			
472	Bracket for link	1	1A	5689			
473	Rivets for bracket	2	5C	2906			
474	Joint pins, for link	2	2K	5221			
475	Joint pin, for bracket	1	2K	5243			
476	Split pins	3	2K	1227			
477	Front brake operating lever	1	1A	5504			

OCT. 1938 FROM CH. 7, 764